www.designworldonline.com October 2018

inside:



D

Motion Control:

How to kill your favorite variable frequency drive

p. 84





Linear Motion:

Linear motors make inroads into test equipment

p. 90






3D CAD:

How driverless cars will change design

p. 106



Aerospace

October 2018

and DEFENSE TIPS



Design equipment faster, smarter, and under budget with TiPS from leading suppliers.



The first cable on the Moon

We all know about "The First Man" on the Moon.

However, when Neil Armstrong took his historic step on the surface of the Moon, he was wearing a bio-belt that was fitted with a Cicoil engineered Biomedical Harness. Without this important piece of the Space puzzle, who can say that the Moon landing would have taken place on July 29, 1969.

Once NASA was established in 1958, the Race for Space between the USA and Soviet Union began. If the United States was to send a man into orbit, walk in Space or to land on the Moon, then vital signs of the astronauts, such as heart rate, blood pressure, respiration, body temperature, and pulse rate would need to be recorded and evaluated.





Quick facts of Cicoil's and NASA's partnership

Cicoil has been a partner to NASA since its inception in 1958.

Cicoil is the only company in history to develop and manufacture a Biomedical Harness that was used successfully on another planetary body — the Moon.

Cicoil was the first company to develop a dedicated zero gravity, low Earth Orbit Biomedical Harness.
Cicoil's Biomedical Harness was the only tested harness design which met IVA (Intravehicular Activity) and EVA (Extravehicular Activity) needs during all phases of the Apollo Space Missions.

Cicoil has proven internal systems and manufacturing processes that meet all Spaceflight requirements. When Neil Armstrong stepped onto the surface of the Moon, he wore the world's first wireless biotelemetry system, which was helped made possible by Cicoil's innovative biomedical harness design concept. Through the use of Cicoil's bioharnesses on the Apollo Space Missions, the first Intensive Care, Emergency Room and Critical Care Unit monitoring systems are introduced.



The actual Bio-Harness used by Neil Armstrong during the Walk on the Moon.

"We all know about "The First Man" on the Moon.
However, when Neil
Armstrong took his historic step on the surface of the Moon, he was wearing a bio-belt that was fitted with a Cicoil engineered Biomedical Harness."



Unlike the Mercury and Gemini missions that focused on historical data, the Apollo missions to the Moon would require continuous monitoring of the astronauts during all intravehicular (IVA) and extravehicular (EVA) activities. Due to the uncertainties associated with the effects of Space flight and normal bodily functions, biotelemetry technology would enable flight surgeons at the Ground Command Center in Houston to identify problems in real time and provide quick solutions.

NASA would need a lightweight, bioinstrumentation harness that could reliably function when continuously exposed to human movement, vibration, zero gravity, and mechanical stress. The cable would need to be flexible, be routed in multiple directions and function well in tight space, especially once placed within the IVA and EVA bio-belts for the Apollo Program flights.


Unfortunately, this task was considered almost impossible due to

the difficulties of working with stiff and bulky round cable, or even loose wires that would not be able to survive constant physical abuse. However, NASA was fortunate to have a cable supplier of specialty molded flat cables who could hopefully provide a flexible solution to an inflexible problem.

Just as they did while developing the Ultra-Flex IDC Flat Ribbon Cable for IBM and the mainframe computer industry, Cicoil's engineers were tasked by NASA to solve this problem. Fortunately, they figured out a way to not just encase twisted pairs of multiple AWG sizes within the same thin flat cable, but to precisely control the spacing between each. By creating this durable cable package, electronic interference and crosstalk would be prevented, and the fully terminated harness would provide uninterrupted signal integrity during the harsh rigors of Space flight.

Unlike, the standard straight ribbon cable design, Cicoil also developed a concept of forming the





Every U.S. astronaut in the history of NASA has worn a Cicoil Biomedical Harness.

cable into various shapes that would save additional space, protect the inner wires during bodily movements and not give up any signal degradation during the entire Space mission. Cicoil was also able to replace stranded wire with extra fine wire into their designs. which would allow the cables to perform exceptionally well in tough environments, but could be formed in 90° angles and even folded over. Up until this time, the concept was not considered a possibility. However, Cicoil's out-of-the-box thinking engineers were once again able to provide yet another innovative solution.

In addition to offering an almost impossible space savings design, Cicoil's biomedical harness was also chosen due to exceptional performance when exposed to temperature extremes (–65° to 260°C); resistance to UV light, radiation, flames, and vibration; high efficiency in dissipating heat between inner cable components; highly flexible and lightweight materials; and high reliability in mission critical applications.

To help prepare for the Apollo 11 Mission to the Moon, the 26-in. long electrical biomedical harness was worn by the astronauts during the Apollo 9 Flight (Commander Jim McDivitt) on March 3, 1969 and the Apollo 10 "Dress Rehearsal" Flight on May 18, 1969. The "Bio-Harness" was worn underneath the Intra-Vehicular Constant Wear Garment when in the Spacecraft, and under the extra-vehicular (EV) pressure suit during Spacewalk activities.

On July 20, 1969, the Cicoil Bio-

Medical harnesses made history by being an integral part of the Historic Apollo 11 First Moon Landing. The Intravehicular Harnesses were worn by Apollo 11 Astronauts on board the Columbia Command Module during the Lunar orbit and the "Eagle" Lunar Module that landed on the Moon's Surface.

The Cicoil Extravehicular Bio-Medical Harness was worn by Apollo 11 Commander Neil Armstrong as he took his historic "First Small Step for Man, and One Giant Leap for Mankind," and was also worn by Eagle Lunar Module Pilot Buzz Aldrin as he took the famous "2nd Walk."

The Cicoil assembly successfully enabled continuous monitoring of all vital signs for each Apollo 11 astronaut during flight, orbit, Moon walk operations and reentry back to Earth. The flawless operational performance of Cicoil's Bio-medical Instrumentation and Telemetry Harness designs were, in NASA's words, "Vital to the successful achievement" of these history-making flights.

In addition to helping NASA put a man on the moon, Cicoil's Biomedical Harnesses were also "there" for the First American to Travel in Space in 1961 (Alan Shepherd), the First American Orbit of the Earth in 1962 (John Glenn), the First Space Walk in 1965 (Edward White) and all Space Shuttle Missions.

Today, Cicoil's Space Flight Approved cable assemblies are utilized on The Mars Rover, Space Transport Rockets, satellites, probes and the International Space Station.

The mission critical success of biotelemetry in Space was just not beneficial to the Apollo Program, it was also beneficial to all of mankind as well. Today, biomedicine is now found in almost all intensive care units, emergency rooms and critical care units throughout the world, and Cicoil is proud to have played an instrumental part in helping to make this "Giant Leap" in medical technology a reality.

